



Ultra Low NOx Atmospheric Vent Models

Gas Water Heaters



SERVICE

MANUAL

Troubleshooting Guide
and Instructions for Service

(To be performed ONLY by
qualified service providers)

Models Covered by This Manual:

UCG100H199*N
UCG100H199*X
UCG100H270*N
UCG100H270*X
(* Denotes Warranty Years)

The Bradford White

Ultra Low NO_x Atmospheric Vent Water Heaters

Table of Contents

	<u>Page</u>	<u>Service Procedure</u>
Introduction	3	---
How to use this manual	4	---
Tool required for service	4	---
Features	5	---
Specifications	6	---
Sequence of Operation	8	---
Troubleshooting	10	---
Thermostat Circuit, Testing & Replacement	27	I
Combustion System Testing and Replacement	31	II
Burner Tube Inspection & Replacement	35	III
Gas Valve Replacement	37	IV
Blower Testing and Replacement	38	V
Flame Sensor Testing and Replacement	40	VI
Spark Rod Replacement	42	VII
Ignition Module/Control Board Replacement	43	VIII
Transformer Replacement	44	IX
Anode Inspection and Replacement	45	X
Display Module Replacement	46	XI
Blocked Vent Switch Inspection and Replacement	47	XII
Heater Service Report	48	---
Parts List	49	---
Glossary of Terms	52	---

Introduction

The Bradford White Ultra Low NOx Atmospheric Vent Water Heater is designed to deliver a remarkable amount of hot water at 82% thermal efficient in a quiet running unit with a top exhaust vent connection that allows for installation in existing locations. While this unit is vented atmospherically there is no damper required to maintain heat loss during off cycle. Several technologically advanced design features are incorporated in the design that will require additional knowledge on the part of the qualified service provider. The information in this manual will instruct service and maintenance professionals on the function, proper diagnosis and repair of The Bradford White Ultra Low NOx Atmospheric Vent Water Heater.

The Bradford White Ultra Low NOx Atmospheric Vent Water Heater uses a ultra low NOx premix power burner located at the top of the water heater to direct a turbulent flame down into the water backed combustion chamber. This turbulence causes a thorough mixing of gas and air for optimum combustion. The combustion gases then travel through a two pass flue system keeping the gases moving at a high velocity. The combination of high turbulence and velocity results in an optimum transfer of heat from the flue gases into the water.

Burner operation is controlled using an electronic ignition module. The module monitors the status of the electronic thermostat, blocked vent limit switch, flame sensor to control output voltage to blower motor, spark rod and gas valve. The module contains programming which determines the sequence of operation and timings for purge periods, trial for ignition, flame sensing and lockout. The module will also provide diagnostic information to help in determining the cause of system lockouts.

The contents in this manual are detailed informational tools to assist in the proper diagnosis of the Ultra Low NOx Atmospheric Vent Water Heater operational faults. Please read this service manual completely and record as much information regarding the Ultra Low NOx Atmospheric Vent Water Heater operation and installation specifics related to any concerns.

How to Use This Manual

It is intended for this manual to be used by qualified service personal for the primary purpose of troubleshooting analysis and repair of the Bradford White Ultra Low NOX Atmospheric Vent Water Heater. Understanding the sequence of operation section of this manual will contribute greatly to troubleshooting this product.

A “Service Report” is shown towards the end of this manual. Completing this form will assist in the troubleshooting efforts. Should you need to call for technical support, please provide the information shown on this form to the support technician to insure accurate troubleshooting.

Troubleshooting begins with “System Observation” to determine failure mode as indicated by the LED status of the ignition module. Troubleshooting continues with “Failure Modes and Probable cause” directing the service provider to a series of test procedures to determine root cause of failure. Component replacement procedures directly follow the test procedures for a given component.

Contact Technical support immediately if diagnosis is not determined using the methods described in this service manual.


Tools Required for Service

Manometer:	Two types available, a liquid “U” tube type or a digital (magna-helic) type. This device is used to measure gas and/or air pressures and vacuum.
Multi-Meter:	A digital type is strongly recommended. This device is used to measure electrical values. The meter you select must have the capability to measure volts AC, volts DC, Amps, micro-amps and ohms.
Thermometer:	Used to measure water temperature. An accurate thermometer is recommended.
Water Pressure Gage:	Used to measure water supply pressure. Also used to determine tank pressure by adapting to the drain valve of the heater.
Jumper Leads:	A length of wire (12" min.) with alligator clip at both ends.
Various Hand Tools:	Pipe wrench, channel locks, open end wrench set, 12" crescent wrench, Allen wrench set, torx bit set, screw drivers (common & Phillips), long reach (12") magnetic tip Phillips head screw driver #2 tip, ¼" nut driver, pliers (common & needle nose), socket set including a 1-1/16 deep well socket, wire cutters, wire strippers, wire crimpers, torpedo level, small shop vac, step ladder, and flashlight.

Features of Honeywell Integrated Control System

- Attractive digital water heater display on control panel for setting and displaying the temperature setpoint. Pressing temperature UP and DOWN buttons changes the temperature setpoint. Same water heater display used on all models. Temperature format may be displayed in °F or °C.
- Single control board with plug in wiring controls temperature, ignition, and blower operation.
- Reduced number of parts for servicing and wiring.
- Plug in wiring reduces chance of miswirng.
- Burner ignition with direct spark ignition - A high voltage spark jumps from the spark rod to the burner surface to ignite the gas.
- Water heater display will show diagnostic codes in the event the water heater needs servicing. Aids in diagnosing and servicing the water heater.
- Water heater display can show previous error code history to further aid in servicing the water heater.

Specifications



Dimensional Layout

Model Number	Capacity		Input Nat. BTU/Hr. Input	1 ST Hour Delivery at 100°F Rise Gal.	GPH Recovery at Degree Rise*			A Floor to Top of Vent in.	B Vent. Dia. in.	C Floor to Cold Water Inlet in.	D Floor to T&P Conn. in.	E Floor to Hot Water Outlet in.	F Floor to Top of Heater in.	G Floor to Gas Conn. in.	H Depth in.	J Width in.	K Floor to Cold Water Inlet/Hot Water Outlet in.	Water Conn. Dia. in.	Gas Conn. Dia. in.	Relief Valve Open in.	Approx. Shipping Weight lbs.
	U.S. Gal.	Imp. Gal.			40°F	100°F	140°F														
UCG-100H-199-3N	100	83	199,999	267	493	197	141	73 1/4	6	10	52 1/2	55 1/2	69 3/4	63 1/4	30	28 1/4	63 1/4	1 1/2	3/4	3/4	632
UCG-100H-270-3N	100	83	270,000	336	665	266	190	73 1/4	6	10	52 1/2	55 1/2	69 3/4	63 1/4	30	28 1/4	63 1/4	1 1/2	3/4	1	632

Model Number	Capacity		Input Nat. kW Input	1 ST Hour Delivery at 56°C Rise Liters	LPH Recovery at Degree Rise*			A Floor to Top of Vent mm.	B Vent. Dia. mm.	C Floor to Cold Water Inlet mm.	D Floor to T&P Conn. mm.	E Floor to Hot Water Outlet mm.	F Floor to Top of Heater mm.	G Floor to Gas Conn. mm.	H Depth mm.	J Width mm.	K Floor to Cold Water Inlet/Hot Water Outlet mm.	Water Conn. Dia. mm.	Gas Conn. Dia. mm.	Relief Valve Open mm.	Approx. Shipping Weight kgs.
	Liters				22°C	56°C	78°C														
UCG-100H-199-3N	379	58.6	58.6	1010	1866	745	533	1861	152	254	1334	1408	1772	1473	762	718	1607	38	19	19	286
UCG-100H-270-3N	379	58.6	58.6	1271	2517	1006	719	1861	152	254	1334	1408	1772	1473	762	718	1607	38	19	25	286

For Propane Gas models change suffix "N" to "X". Example: UCG-100H-199-3X

Specifications

Honeywell Integrated Control System

Power supply	Dedicated 120 VAC, 60 Hz, 15A
Gas Supply	Minimum 3/4"NPT for 300,000 BTU's/hr. and below. Minimum 1" NPT for 399,999 BTU's/hr. (schedule 40 black iron pipe recommended)
Approved Gas Type	Natural or Propane. Gas supply must match the gas type listed on the water heater rating label.
Gas Pressure (Nat.& L.P.)	14.0" W.C. maximum static, 4.5" W.C. minimum running (recommend 7.0" W.C. min running)
Venting System	Atmospherically Vented, Type B venting system or approved chimney. Follow the current National Fuel Gas Code requirements or in Canada, the Natural Gas and Propane Installation Code.
Minimum Clearance for Servicing	18" from the top, 24" from the front, 4" from sides and rear
Maximum Water Supply Pressure	150 PSI
Thermostat Sensor	11,900 Ohms @ 70°F, ECO opens @ 207°F Max. Redundant sensor for ECO. Sensor inside a dry well for easy replacement of sensor.
Control Display	Digital display, 24 volts. Temperature Range: 70-180 deg. F. Used to set tank temperature (deg. F or deg. C), show operating status, Display error codes, error code history, limit maximum setpoint temperature.
Control Board	Operates from 24 volt from transformer. Controls tank temperature, ignition functions, combustion blower. See ignition timings in sequence of operation for Integrated Control.
Transformer	120VAC primary, 24VAC secondary, 40VA.
Spark Rod Igniter	0.22" nominal gap to the burner surface.
Flame Sensor Output	Minimum 1 micro amp, Typical range 5 to 30 micro amps.
Gas Valve	Negative regulation, 24 VAC, 1/2" PSI max., 4.5" W.C. Minimum running inlet.
Blocked Vent Safety Switch	Normally closed, opens @ 240°F, manual reset.
Blower	120VAC, 60Hz, .6-1 amps, 6400 RPM.
Combustion Levels	CO2: 10-11%, CO: less then 0.04 percent (400 PPM) air free

Sequence of Operation

For models with Honeywell Integrated Control System w/ Direct Spark Ignition

- 1 Thermostat calls for heat.
- 2 Combustion blower starts.
- 3 Blower pre-purge period of 30 seconds.
- 4 Trial for Ignition. (5 seconds, 3 trials).
 - Flame establishing period (3 seconds), gas valve opens, sparks from spark rod to burner surface to ignite the gas.
 - Burner on, flame proving period (2 seconds). Requires a minimum of 1 microamp through flame sense rod to prove flame per specs on page 7.
 - If the blocked vent safety switch contacts (normally closed) are open after being energized, then the ignition sequence will not start and an error code 26 (Safety switch circuit opened) will be shown on the display.
- 5 Steady State Operation: Burner continues to operate until:
 - Thermostat circuit opens, gas valve closes, blower continues to operate for 30 second post-purge period.
 - If the normally closed blocked vent safety switch opens, the gas valve closes, the blower post-purges, then shuts off with error code 26 displayed in a lockout condition.
- 6 Thermostat satisfied.
- 7 Gas valve closes, burner extinguished.
- 8 Blower post purge for 30 seconds.

Sequence of Operation


For models with Honeywell Integrated Control System w/ Direct Spark Ignition

Lockout Conditions (Complete list of error codes is listed on the unit)

The system will go into lock out mode for the following reasons:

- ERROR CODE 26**
 If the blocked vent safety switch mounted on the draft hood should open, the gas valve will close, the blower will post-purge and error code 26 will appear on the display. The lockout condition will reset once the problem is corrected and the switch reset. Refer to "Vent Safety Switch Testing and Replacement" in this Service Manual.
- ERROR CODE 62 or 63**
 Control board will go into "Soft Lockout" if the main burner cannot be lit or fails to prove flame after 3 ignition trials. The water heater display indicates a lockout condition by showing an error code number (62 or 63) with "Service Needed" in the control display window. Refer to error codes in the diagnostic section of this Service Manual. In a "Soft Lockout" condition, the control will wait for 60 minutes and then make 3 more attempts to light the main burners. Soft lockout reset is accomplished by depressing the lower right button under "Reset" for 3 seconds.
- ERROR CODE 65**
 If the top of the tank should exceed 207°F, then the high limit control will shut off the burner and the water heater will go into a "Hard Lockout". Error code 65 will be shown in the water heater display. The control can only be reset in the "Service Mode", which is detailed in the "Troubleshooting" section of this Service Manual.

CONNECTION/WIRING DIAGRAM



Troubleshooting

System Observation
For models with Direct Spark Ignition

Water Heater Fault: Water heater does not operate
Display Error Code: Water heater display does not operate - blank display

Check main power supply to water heater - fuse, circuit breaker, plug receptacle, line cord or wiring to water heater.

Check to make sure switch on front of control panel is in the ON position

Verify Primary voltage at the control board.


Verify Secondary voltage at the control board.

WARNING
120 volt potential exposure. Use caution making voltage checks to avoid personal injury.

CAUTION
Use caution not to damage connectors when making voltage measurements or jumping terminals

Refer to Control Board illustration. Voltage at primary pins **P2(1) & P2(3)** will be 110-120. If not, check Line In pins **P3(1) & P3(4)**. Check line cord with volt meter. Replace line cord if defective.

Refer to Control Board illustration. Voltage at secondary pins **P4(1) & P4(2)** will be 24VAC. If not, replace transformer or wire harness.



Does water heater display operate? Does the combustion blower start to operate? Increase thermostat setting if tank is warm.

Display Operates - See next page

Is 24VAC present between **RED** and **BLACK** wire pin connections on the back of Control Display?

Check wires for proper termination to control display. Are wire terminations connected properly to control display?

Replace Control Display.

Is 24VAC present between E-COM screw terminals **P9(2) & P9(3)** on the Control Board.

Check wire harness for proper continuity

Make proper wire terminations

Replace Control Board

Troubleshooting



System Observation
For models with Direct Spark Ignition



WARNING
120 volt potential exposure. Use caution making voltage checks to avoid personal injury.



CAUTION
Use caution not to damage connectors when making voltage measurements or jumping terminals




Troubleshooting


Accessing Service Mode on Control Display For models with Honeywell Integrated Control

The display has a “service mode” for changing the maximum setpoint and accessing information in aiding servicing of the water heater. This procedure is for service and installation personnel only. To enter the Service Mode, follow the steps illustrated below:

Step 1: Press “Select” and “Temperature Up” buttons together and hold for 3 seconds until “Max Setpoint” is shown in the display.




Step 2: Pressing “Select” button will change display to next mode



The following is the sequence of modes available in “Service Mode” by pressing the “Select” button:


Error Code Number (Display/Reset). This is only shown if there is an operating error in the “User Mode”.
Error Code Shown in Water Heater Display




Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control


1. Max Setpoint (Display/Change)



2. Tank Sensor Temperature Displayed Water Temperature Average.




3. Flame Current of Burner Flame Sensor (Displays only in the Heating Cycle)




Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control


4. Setpoint (Display/Change)



5. °F/°C (Display/Change)




6. Differential (Display only - shows the differential of the thermostat)




Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control

7. Software Version (Display only)



8. Error Code History (Displays if there are present error codes or up to 10 previous error codes see page 22). Water Heater Display will show a "--" if there are no error codes.




To change the Maximum Setpoint Limit (Max Setpoint) for the temperature setpoint:

Step 1: In service mode press the "Select" button until "Max Setpoint" is displayed.

WARNING


Setting the water temperature to the maximum set point can result in scalding hot water delivered to the faucets. It is highly recommended that the maximum setpoint be adjusted to the lowest temperature possible for the needs of the installation. Make sure the water heater control display is not in a public area that can result in the temperature settings being improperly adjusted.




Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control


Step 2: Press "Set" button to enter setting mode. "Max Setpoint" will flash to indicate setting mode.



Step 3: Press the "UP" or "DOWN" buttons to change the maximum setpoint value. This will limit the maximum setpoint the user can select. Note: The maximum setpoint is approximately 180°F.




Step 4: Press "Set" button to confirm new "Max Setpoint" value and stop setting mode.



Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control


Step 5: 30 Seconds after the last button press, the Water Heater Display will go back to "User Mode". It will read "Max Setpoint" without showing a temperature value if the temperature setpoint is at the maximum setting. The Water Heater Display can be set back to the "User Mode" immediately by pressing both the "Temperature Up" and "Select" buttons together for 3 seconds.



Exiting Service Mode

Display of Water Temperature:

Step 1: In Service Mode, Press the "Select" button until "Water Temp" is displayed in the upper right section of the water heater display. This is the reading for the sensor.




Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control


To Display Flame Sense Current of the Flame Sensor:

The flame sense current is available only when the burners are in operation. Step 1: Make sure the status displays "Heating" or draw enough hot water to start the burners. Step 2: Enter the "Service Mode" described previously. Step 3: Press the "Select" button until a number value is displayed with "Flame Current" to the right of the number. The value displayed is in microamps (μA).



To Display and Change Temperature Setpoint:


Step 1: In "Service Mode" press the "Select" button until "Setpoint" is shown in the water heater display



Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control

Step 2: Press the "Set" button to enter the setting mode. "Setpoint" will flash in the water heater display.




Step 3: To raise the temperature setpoint, press the "Temperature Up" button until the desired temperature is shown on the water heater display.

NOTICE


The maximum temperature that can be set in the Water Heater Display is limited to the "Max Setpoint" described previously. To change the "Max Setpoint", refer to the procedure "To Change the Maximum Setpoint Limit..." described previously under "Accessing the Service Mode on the Water Heater Display".

WARNING

Setting the water temperature to the maximum set point can result in scalding hot water delivered to the faucets. It is highly recommended that the maximum setpoint be adjusted to the lowest temperature possible for the needs of the installation. Make sure the water heater control display is not in a public area that can result in the temperature settings being improperly adjusted.




Step 4: To lower the temperature setpoint, press the "Temperature Down" button until the desired temperature is shown on the water heater display.



Troubleshooting

Accessing Service Mode on Control Display For models with Honeywell Integrated Control


Step 5: When the desired setpoint is reached on the water heater display, press the “Set” button to confirm the new setpoint. “Setpoint” stops flashing in the water heater display.




To Display and Change Temperature Format (°F/°C):

To Change Temperature Format in Display from °F to °C or °C to °F:

Step 1: While in “Service Mode”, press “Select” button until “°F/°C” is shown in the upper right portion of the water heater display.




Step 2: Press “Set” button to change temperature format. “°F/°C” symbol will flash in the water heater display.




Troubleshooting

Accessing Service Mode on Control Display
For models with Honeywell Integrated Control


Step 3a: Press "Temperature Up" button to change temperature format to °C



Step 3b: Press "Temperature Down" button to change temperature format to °F




Step 4: Press "Set" button to confirm °F or °C format. °F/°C will stop flashing



Troubleshooting


Accessing Service Mode on Control Display For models with Honeywell Integrated Control

Step 5: Pressing “Select” button will return display to setpoint in format selected (°F or °C) immediately



Error Codes and Error History Display:

If there is an operating problem with the water heater, an error code number will appear on the water heater display with “Service Needed” to the right of the “Status” indicator. The error code label is located under the Water Heater Display and the following section in this Service Manual explains the error codes with corrective actions to repair the water heater.



Example of Error Code in the Display

Error Code History:

In “Service Mode” pressing the “Select” button after the “Software Version” (item 8 in the previously described sequence of service modes) will show an error code history, if there have been any previous operating problems with the water heater. If the display shows --, there is not a current error code.


The Water Heater Display will provide up to 10 previous error codes. The oldest error code will be stored in code index #1 and the most recent in code index #10.

Troubleshooting


Accessing Service Mode on Control Display
For models with Honeywell Integrated Control

To view previous error codes:


Step 1: In "Service Mode" press the "Select" button until the next display after the "Software Version". If there are no current error codes, the display will show -- .



Step 2: Press the "Temperature Down" button to select the error code index, starting with the most recent error code "10".




Step 3: Press the "Select" button to view the error code for "code 10". If there is a number displayed, note what the number is. The label next to the water heater display will identify the code number. If no number is displayed with only a "--" in the water heater display, then there has not been an error code for error code index 10.




Troubleshooting

Accessing Service Mode on Control Display For models with Honeywell Integrated Control

Step 4: Press the “Temperature Down” button to change to the previous code index, code #9.




Step 5: Press the “Select” button for code index #9 to view if there are any code numbers.



Step 6: Continue pressing the “Temperature Down” button to change to the next error code index and press “Select” to view the error code number, if any, for that index number. Continue on to index #1, the oldest error code index. The water heater display will store up to 10 error codes with the oldest code starting in code index #1 with the most recent code in code index #10.

Step 7: 10 seconds after the last button press, the Water Heater Display will revert back to the current error code display. To exit Service Mode, either wait 30 seconds or press Temperature Up button and Select Button for 3 seconds.



Exiting Service Mode

Troubleshooting

Error Code Definitions
For models with Honeywell Integrated Control

ERROR CODE DEFINITIONS

If the water heater has an operating problem, there will be a number in the water heater display with "Service Needed" shown below the error code number. Note the error code and the definition in the chart below. This label appears on the control box under the water heater display. The following sections will provide instructions for servicing each error code.

HONEYWELL INTEGRATED CONTROL ERROR CODES	
ERROR CODE	DEFINITION
4	LOW FLAME SENSE CURRENT
6	FLAME SENSED OUT OF NORMAL SEQUENCE (BEFORE OPENING GAS VALVE OR AFTER CLOSING GAS VALVE)
23	FLAME DETECTED BEFORE IGNITION
24	FLAME DETECTED AFTER A HEATING CYCLE COMPLETES
26	BLOCKED VENT SWITCH OPENED-POSSIBLE VENT BLOCKAGE
32	TEMPERATURE SENSOR READINGS FAULTY
57	FLAME ROD SHORTED TO GROUND
58	AC LINE FREQUENCY ERROR – SIGNAL TOO NOISY OR FREQUENCY INCORRECT
59	LINE VOLTAGE TOO LOW OR HIGH
61	DC OUTPUT VOLTAGE UNSTABLE
62	MAXIMUM NUMBER OF RETRIES DETECTED
63	MAXIMUM NUMBER OF IGNITION RECYCLES DETECTED
64	ELECTRONICS FAILURE
65	HIGH WATER TEMPERATURE (OVER 200°F)

IF ANY OF THE ABOVE CODES APPEAR ON THE CONTROL DISPLAY, CONTACT YOUR PLUMBER OR QUALIFIED SERVICE AGENT FOR SERVICE OF THIS WATER HEATER.


Troubleshooting

Resetting Error Codes
For models with Honeywell Integrated Control

⚠ WARNING


The following procedure is for service and installation personnel only. Resetting lockout conditions without correcting the malfunction can result in a hazardous condition.

If an error code is displayed (except for #4, low flame sense current), the water heater will be in a “lockout condition” with the water heater display showing the error code number and “Service Needed” in the status section of the display window. Error codes 62 (maximum number of retries detected) and 63 (maximum number if ignition recycles detected) are “Soft Lockouts” in which the control can be reset in the “User Mode” by pressing the lower right button under “Lockout Reset” shown in the lower right portion of the display. The control will also go through 3 attempts to relight the burners every hour in the soft lockout condition.



All other error codes will put the water heater into a “Hard Lockout” condition, in which the water heater will not operate and cannot be reset in the “User Mode”. To reset a hard lockout, first enter the “Service Mode” described earlier by pressing both the “Temperature Up” and “Select Buttons” at the same time for 3 seconds. Then press the lower right button under “Lockout Reset” in the water heater display and hold for 3 seconds.

Resetting Error Codes in Hard Lockout Condition



SERVICE PROCEDURE I

Thermostat Circuit Testing and Replacement

IMPORTANT NOTE: This procedure assumes a cool tank

Condition: Water Heater Not Operating
Display shows error code "32"
(Sensor Reading Faulty)

Unplug or disconnect electrical power to the water heater

Check continuity of wire harness to sensor. Resistance of harness should be close to 0 ohms. Replace wire harness if high resistance is measured (over 0.5 ohms) Check wires for intermittent connections, shorts, frayed insulation. Replace if necessary

If wire harness is O.K., check sensor resistance detailed in "Appendix - A: sensor resistance at various temperatures" at the end of the thermostat testing and replacement section. Replace sensor if needed.


Turn power ON to water heater.
 Run water heater through heating cycle and verify proper operation. Sensor temperature can be viewed when burner shuts off (see section on viewing the display in "Service Mode").

Condition: Water Heater Not Operating
Display shows error code "65"
High Water Temperature (over 200 °F)

WARNING
Do not reset the display from the hard lockout state without correcting the cause of the overheating condition


Turn power "OFF".
 Draw water to cool tank below 120 °F

Check sensor. Sensor is held in place with a clip fastened to the well (see photo). Check sensor wire for potential damage or breaks in the wire insulation. Is the sensor fully inserted into the well?



⚠ WARNING
120 volt potential exposure. Use caution making voltage checks to avoid personal injury.


⚠ CAUTION
Use caution not to damage connectors when making voltage measurements or jumping terminals



Checking continuity of sensor (disconnected at Control Board)



Sensor shown fully inserted into well



Sensor clip shown installed properly

SERVICE PROCEDURE I

Thermostat Circuit Testing and Replacement

Condition: Water Heater Not Operating
Display shows error code "65"
High Water Temperature (over 200 °F)
(Continued from previous page)


⚠ WARNING
Do not operate water heater without verifying that the overheating condition has been corrected.

Once cause of overheating condition has been diagnosed and corrected, the control may be reset

- Reconnect and switch on power to the water heater.
- Enter service mode on the water heater display (see illustration)
- Press button under "Lockout Reset" and hold for 3 seconds.
- Set thermostat to the desired setting.
- Water heater will start.
- Monitor temperatures for one complete heating cycle making sure the maximum tank temperature remains well below 200 °F

This water heater is equipped with a manual reset type gas shutoff device designed to shut off the gas to the burners if excessive water temperature occurs. To reset the control, first press the "temperature up" and "select" buttons on the water heater display for 3 seconds to enter service mode. Then press the lower right button under "RESET" in the display for 3 seconds.

Error code 65 indicates high limit lockout condition



SERVICE PROCEDURE I

Thermostat Circuit Testing and Replacement

APPENDIX - A

Sensor Resistance at Various Temperatures

*Be Careful When Making Voltage Measurements or Jumping Terminals
Not to Damage or Deform Connectors or Connector Pins.*

**Draw Water From The T&P Valve. Compare Temperature With
Temperature Ohms Chart Below.**

Example: If temperature of sensor is 84°F, then the resistance through the sensor would be 8449 (see shaded area).
NOTE: Sensor resistance increases as the temperature falls.

In Degrees F										
°F	0	1	2	3	4	5	6	7	8	9
40	26109	25400	24712	24045	23399	22771	22163	21573	21000	20445
50	19906	19383	18876	18383	17905	17440	16990	16553	16128	15715
60	15314	14925	14548	14180	13823	13477	13140	12812	12494	12185
70	11884	11592	11308	11032	10763	10502	10248	10000	9760	9526
80	9299	9078	8862	8653	8449	8250	8057	7869	7685	7507
90	7333	7165	7000	6839	6683	6531	6383	6238	6098	5961
100	5827	5697	5570	5446	5326	5208	5094	4982	4873	4767
110	4663	4562	4464	4368	4274	4183	4094	4006	3922	3839
120	3758	3679	3602	3527	3453	3382	3312	3244	3177	3112
130	3048	2986	2925	2866	2808	2752	2697	2643	2590	2538
140	2488	2439	2391	2344	2298	2253	2209	2166	2124	2083
150	2043	2004	1966	1928	1891	1856	1820	1786	1753	1720
160	1688	1656	1625	1595	1566	1537	1509	1481	1454	1427
170	1402	1376	1351	1327	1303	1280	1257	1235	1213	1191
180	1170	1150	1129	1110	1090	1071	1053	1035	1017	999
190	982	965	949	933	917	901	886	871	857	842
200	828	814	801	788	775	762	749	737	725	713

*Be Careful When Making Voltage Measurements or Jumping Terminals
Not to Damage or Deform Connectors or Connector Pins.*




SERVICE PROCEDURE I

Thermostat Circuit Testing and Replacement

Thermostat Sensor (Thermister) Replacement Procedure

- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Un-latch and remove top surround cover from top of heater.
- Step 4. Unclip sensor connector from control board and remove harness from control panel (see picture).
- Step 5. Unclip sensor from well and pull sensor to remove, do not remove well (see picture).
- Step 6. Install new sensor assembly into well and reinstall sensor clip.
- Step 7. Reconnect the sensor connector to the control board and route the wire harness through the same path that it was removed.
- Step 8. Restore 120 volt power supply. Confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.
- Step 9. Replace surround cover on top of heater.

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.




SERVICE PROCEDURE II

Combustion System Testing and Replacement



Observe burner operation through the sight glass located on the combustion insert mounting flange. Normal burner operation should ignite smoothly, without evidence of coughing or huffing upon ignition. The burner flame should be a blue flame near the burner surface in a uniform flame pattern. Occasional yellow or white streaks are normal.

Note: Models using metal fiber mesh burner a red glow from the burner surface is normal.




WARNING
Removing screw from inlet gas pressure tap will immediately allow gas to flow from pressure tap.

WARNING
120 volt potential exposure. Use caution making voltage checks to avoid personal injury.




Voltmeter set to OHM setting



Spark Rod

Volt meter set to OHM setting




CHECK SPARK ROD RESISTANCE

SERVICE PROCEDURE II

Combustion System Testing and Replacement

Observe burner operation through the sight glass located on the combustion insert mounting flange. Normal burner operation should ignite smoothly, without evidence of coughing or huffing upon ignition. The burner flame should be a blue flame near the burner surface in a uniform flame pattern. Occasional yellow or white streaks are normal.



SERVICE PROCEDURE II

Combustion System Testing and Replacement


⚠ WARNING
Heater components may be **HOT** when performing the following steps in this procedure.
Take necessary precaution to prevent personal injury.

Combustion System Removal Procedure

- Step 1. Position main power switch to "OFF".
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Turn off gas supply to water heater.
- Step 4. Un-latch and remove surround cover from top of heater.
- Step 5. From the gas valve, disconnect the gas connection, PVC intake assembly, silicone tubing and wire harness.
- Step 6. Disconnect wire harnesses to the flame sensor, spark rod connection, blower, and gas valve.

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.

- Step 7. Remove 5 bolts (1/2" socket) holding the burner mounting insert in place.
- Step 8. Carefully remove combustion assembly with gasket from water heater.
- Step 9. See next page for combustion system installation procedure.



SERVICE PROCEDURE II


Combustion System Testing and Replacement

Combustion System Replacement Procedure

- Step 1. Fully inspect burner gasket for the following:
- a) Tears
 - b) Missing material
 - c) Cracks
 - d) Dirt or debris
 - e) Other imperfections that would inhibit proper seal

If gasket is NOT affected by any of the above, gasket replacement is not required.

- Step 2. Install combustion system using new gasket or fully inspected gasket from step 1. Secure the combustion at the burner mounting insert using the bolts from step 7 on previous page. Tighten the nuts evenly
- Step 3. Reconnect high voltage cable to spark rod, flame sensor, blower and gas valve.
- Step 4. Reconnect intake assembly, gas supply and silicone tubing to gas valve. Turn on gas supply to heater and check for gas leaks, repair any gas leaks found.
- Step 5. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.
- Step 6. Replace surround cover on top of water heater.



SERVICE PROCEDURE III

Burner Tube Inspection and Replacement

⚠ WARNING

Heater components may be **HOT** when performing the following steps in this procedure. Take necessary precaution to prevent personal injury.


Burner Tube Removal Procedure

- Step 1. Position main power switch to "OFF".
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Turn off gas supply to water heater.
- Step 4. Un-latch & remove surround cover from top of heater.
- Step 5. From the gas valve, disconnect the gas connection, intake assembly, wire harness and silicone tubing.

⚠ WARNING

120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.

- Step 6. Disconnect wire harness from blower assembly.
- Step 7. Remove the two screws holding each the direct spark igniter and flame sensor in place (long reach magnetic Phillips screw driver). Carefully remove direct spark igniter and flame sensor from combustion assembly.
- Step 8. Remove the 4 nuts (7/16" wrench) holding the burner transition in place. Lift the blower/gas valve transition assembly from burner mounting insert, remove gasket and set aside.
- Step 9. Remove burner tube from burner mounting insert. See next page for burner tube inspection procedure.



SERVICE PROCEDURE III

Burner Tube Inspection and Replacement

 **WARNING**

Heater components may be **HOT** when performing the following steps in this procedure.
Take necessary precaution to prevent personal injury.

Burner Tube Inspection

- Step 1. a) Outer fiber mesh should be uniform with no tears or deterioration.
 b) Gently squeeze burner tube, Burner tube should feel firm without any soft areas around the sides or at the bottom.
 c) Visually inspect inside burner tube, Burner tube should be intact with no areas of deterioration. Ports should be free of any debris.
- Step 2. If burner tube is affected by any of the above, replacement is required. Refer to burner tube replacement procedure below.

Burner Tube Replacement Procedure


- Step 1. Fully inspect burner flange gaskets, igniter and flame sensor gaskets for the following:
- | | |
|---------------------|---|
| a) Tears | d) Dirt or debris |
| b) Missing material | e) Other imperfections that would inhibit proper seal |
| c) Cracks | |
- If gaskets are NOT affected by any of the above, gasket replacement is not required.
- Step 2. Install burner tube with gaskets into mounting assembly. Be sure gasket surfaces are free of debris.
- Step 3. Reinstall the burner transition with combustion assembly attached with the nuts that were removed from step 8 on previous page. Tighten the nuts evenly.
- Step 4. Carefully reinstall flame sensor with gasket and direct spark igniter (DSI) with gasket and secure with screws from step 7 on previous page. .
- Step 5. Reconnect wire harnesses to the flame sensor, spark rod connection, blower and gas valve.
- Step 6. Reconnect the intake assembly, gas supply and silicone tubing to gas valve. Turn on gas supply to heater and check for gas leaks, repair any gas leaks found.
- Step 7. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.
- Step 8. Replace surround cover on top of water heater.

Service Procedure IV Gas Valve Replacement

Gas Valve Replacement Procedure

- Step 1. Position main power switch to "OFF".
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Turn off gas supply to water heater.
- Step 4. Un-latch & remove surround cover from top of heater.
- Step 5. From the gas valve, disconnect the gas connection, intake assembly, wire harness and silicone tubing.
- Step 6. Remove the 2 gas valve mounting screws (Torx bit) located at the 2:00 O'clock & 8:00 O'clock position on the venturi mounting flange and remove gas valve from water heater.
- Step 7. Remove any residual gasket material from blower and venturi mounting flange.

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.



- Step 8. Install new gas valve with new gasket provided. Secure gas valve in place using screws from step 6.
- Step 9. Reconnect PVC venting, gas supply, silicone tubing & wire harness to gas valve. Turn on gas supply to heater and check for gas leaks, repair any gas leaks found.
- Step 10. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.
- Step 11. Replace surround cover on top of water heater.


Service Procedure V

Blower Testing and Replacement

Blower Replacement Procedure

- Step 1. Position main power switch to "OFF".
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Turn off gas supply to water heater.
- Step 4. Un-latch & remove surround cover from top of heater.
- Step 5. Disconnect wire harness from blower.
- Step 6. Disconnect intake vent and gas supply from gas valve assembly.
- Step 7. Remove the 2 gas valve mounting screws (Torx bit) located at the 3:00 O'clock & 7:00 O'clock position on the venturi mounting flange.
- Step 8. Remove The 4 blower flange mounting screws (5/32 Allen wrench) and remove blower from transition flange.

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.





- Step 9. Remove any residual gasket material from venturi mounting flange and transition flange.
- Step 10. Install new blower with new gasket provided. Secure blower in place using screws from step 8.
- Step 11. Reconnect gas valve assembly to blower with new gasket provided. Secure gas valve in place using screws from step 7.
- Step 12. Reconnect intake vent and gas line to gas valve assembly and check for gas leaks repair any leaks found.
- Step 13. Reconnect wire harness to blower assembly, restore 120 volt power supply & Gas supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instructions located in the installation and operating instruction manual.
- Step 14. Replace surround cover on top of water heater.

Service Procedure VI

Flame Sensor Testing and Replacement

Flame Sensor Testing Procedure

⚠ WARNING
 120 volt potential exposure. Use caution making voltage checks to avoid personal injury. Flame sensor may be too hot to handle, take necessary precautions



DIRECT SPARK IGNITION MODELS



Service Procedure VI

Flame Sensor Testing and Replacement

Flame Sensor Replacement Procedure

- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Un-latch & remove surround cover from top of heater.
- Step 4. Disconnect wire lead from flame sensor.
- Step 5. Remove the 2 sensor mounting screws (magnetic tip, long reach Phillips screw driver) and remove flame sensor & gasket from transition base flange.
- Step 6. Remove any residual gasket material from transition base flange.
- Step 7. Install new flame sensor with new gasket provided using screws from step 5. Arrange flame sensor with hook towards burner.
- Step 8. Reconnect flame sensor wire.
- Step 9. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instructions located in the installation and operating instruction manual.
- Step 10. Replace surround cover on top of water heater.

WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.






SERVICE PROCEDURE VII

Spark Rod Replacement

Spark Rod Replacement Procedure

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.

- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Un-latch & remove surround cover from top of heater.
- Step 4. Disconnect wire lead from spark rod.
- Step 5. Remove the 2 mounting screws (magnetic tip, long reach Phillips screw driver) and remove spark rod & gasket from transition base flange.
- Step 6. Remove any residual gasket material from transition base flange.
- Step 7. Install new spark rod with new gasket provided using screws from step 5. Arrange spark rod with hook towards burner (Off-center mounting hole only allow installation one way).
- Step 8. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instructions located in the installation and operating instruction manual.
- Step 9. Replace surround cover on top of water heater.





Service Procedure VIII

Ignition Module/Control Board Replacement

Control Board Replacement

- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Un-latch and remove top surround cover from top of water heater.
- Step 4. Locate control board.
- Step 5. Carefully disconnect all wire connections from control board (Identify all wire connections)
- Step 6. Depress tabs on the top of control first then tilt the control forward.
- Step 7. Unhook the tabs on the control out of the slots on the control panel and remove control.
- Step 8. Replace control board and all wire connections.
- Step 9. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.
- Step 10. Replace surround cover on top of water heater.

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.



Service Procedure IX

Transformer Replacement

Transformer Replacement Procedure

- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Un-latch and remove top surround cover from top of water heater.
- Step 4. Disconnect primary leads (black & white & green) and secondary leads (blue & yellow) from the control board.
- Step 5. Remove the 2 nuts (11/32 nut driver) holding the transformer in place and remove transformer from control panel. (see photo right)
- Step 6. Install new transformer and secure in place with nuts from step 5.
- Step 8. Reconnect primary and secondary wires from transformer to control board.
- Step 9. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.
- Step 10. Replace surround cover on top of water heater.



WARNING

120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.

Step 5

Remove transformer mounting nuts



Service Procedure X

Anode Inspection and Replacement


Anode inspection and replacement

WARNING


Heater components and stored water may be **HOT** when performing the following steps in this procedure. Take necessary precaution to prevent personal injury.

- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Turn off water supply and drain water heater.
- Step 4. Locate (see photo below) and remove anode rods from heater (1-1/16 hex socket).
- Step 5. Visually inspect anode rod. Anode rod should show signs of depletion, this is normal. If the depletion is $\frac{1}{2}$ of the original diameter (approximately $\frac{3}{4}$ " diameter), replacement is recommended. If any of the steel core of the anode is exposed, replacement is recommended.
- Step 6. Upon completion of inspection or subsequent replacement, apply thread sealing tape or other thread compound to threads of anode and reinstall into heater. Restore water supply and check for and repair any leaks found.
- Step 7. Restore 120 volts to water heater and verify proper heater operation following the instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.

Top of water heater.
Anodes located under plastic covers by the inlet and outlet water connections.



Cut Access hole thru insulation.
After removing insulation you will have access to the anodes



Service Procedure XI

Display Module Replacement

Display Module Replacement


- Step 1. Position main power switch to "OFF"
- Step 2. Disconnect (unplug) water heater from 120 volt power source.
- Step 3. Remove four screws that hold the display into the enclosure (shown on the right).
- Step 4. After removing the screw pull the display out of the enclosure.
- Step 5. Once the display is removed disconnect the two mating plugs.
- Step 6. Connect in new display and replace into the enclosure.
- Step 7. Use the four screws from step 3 and reinstall the display onto the enclosure.
- Step 8. Restore 120 volt power supply to water heater and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.

⚠ WARNING
120 volt potential exposure. Isolate the appliance and reconfirm power is disconnected using a multi-meter.

Display and Enclosure





Disconnect



Service Procedure XII

Blocked Vent Switch Inspection and Replacement

- Step 1. First determine if the "Blocked Vent Switch" was installed correctly on the draft hood (see picture right).
- Step 2. When Error Code 26 is present you first must determine if there is a blocked vent condition present. If so, clear the obstruction and reset the switch then continue with normal operation.
- Step 3. If the switch is tripped and there is no obstruction in the venting there could have been an extended down draft that tripped the switch. The down draft could have been caused by damage vent termination. Contact your plumbing professional to correct this issue.
- Step 4. When no blockage or downdraft issues are present check the continuity of the switch (see photo below). If there is no continuity present even when switch is reset the blocked vent switch assembly needs to be replaced.
- Step 5. If blocked vent switch assembly is functioning correctly check to see if the wire harness has any signs of damage. Replace harness if any signs of damage exist.
- Step 6. Restore water heater to use and confirm proper operation following the lighting instructions on the lighting instruction label or the lighting instruction located in the installation and operating instruction manual.



UCG100 Heater Service Report

Date _____

Service Provider _____

Model Number _____

Phone Number _____

Serial Number _____

Venting:

Vent 6", 7" or 8" _____

Number of elbows _____

Horizontal length _____

Vertical length _____

Gas Line:

Size & material _____

Distance from meter
to water heater _____

Gas Pressure:

Static _____

Running Inlet _____

Manifold _____

Venturi:

Setting from Bottom in Turns _____

Electrical:

Line Voltage _____

Low Voltage _____

Polarity _____

Spark Rod Resistance: _____

Flame Sense Micro -Amps: _____

Flame Sense
Resistance: _____

Error Codes on Control Display (Direct Spark Ignition): _____


Combustion: CO2 _____

CO _____

Installation Site Name & Address:

**Installation Site Contact Name & Phone
Number**

Parts List



U Model – Water Heater

1	Surround Assembly
2	Combustion Assembly (Specify model)
3	Ignition Control Assembly
4	Draft Hood (Specify model)
5	Latch
6	Front Outlet Nipple
7	Baffle 2" Flue (Specify Model)
8	Display Module
9	Front Inlet Diptube
10	Plastic Hole Closure
11	No Handle Brass Drain Valve
12	Cleanout Cover
13	Screw 5/16-18 x 3/4" HH Grade 5
14	Cleanout Access Cover (Specify Model)
15	T&P (Specify Model)
16	Top Hot Water Outlet Nipple
17	Anode
18	Top Cold Water Inlet (Hydrojet)


Customer must specify complete model number and serial number when ordering service parts.

Parts List

Combustion Assembly

1	Combustion Assembly (Specify model)	14	Igniter – Direct Spark Ignition
2	Blower/Gas Valve Assembly (Specify model)	15	Burner (Specify Model)
3	Burner Assembly (Specify model)	16	Sight Glass
4	Blower – (Specify model)	17	Burner Mount Plate
5	Venturi Gasket	18	3/4" to 1/2" Reducer Bushing
6	Transition Tube	19	Nipple
7	Gasket Blower Transition	20	Gas Valve (Specify Model)
8	Gasket Burner (Specify Model)	21	Venturi (Specify Model)
9	1/4 – 20 Nut		
10	Screw 8-32 x 1/4" RHCR		
11	Gasket Flame Sense		
12	Gasket Igniter		
13	Sensor – Flame Sense		


Customer must specify complete model number and serial number when ordering service parts.



Parts List

Ignition Control Assembly and Harnesses

1	Control Panel	9	Hex Nut
2	Control	10	Ignition Control Harness
3	Transformer	11	Power Cord Harness
4	Display Panel	12	T-Stat Sensor Harness
5	Screw	13	High Voltage Spark Cable
6	Switch Main Power	14	Blower/Circ/Damper Harness
7	Control Display	15	Ground Wire
8	Weld Stud	16	Flame Sense Harness



Customer must specify complete model number and serial number when ordering service parts.



BRADFORD WHITE®

W A T E R H E A T E R S

Ambler, PA

For U.S. and Canada field service,
contact your professional installer or
local Bradford White sales representative.

Sales/800-523-2931
Fax/215-641-1670
Parts Fax/215-641-2180

Technical Support/800-334-3393
Fax/269-795-1089

Warranty/800-531-2111
Fax/269-795-1089

International:
Telephone/215-641-9400
Telefax/215-641-9750



BRADFORD WHITE-CANADA® INC.

Mississauga, ON

Sales/866-690-0961
905-238-0100

Fax/905-238-0105

Technical Support/800-334-3393

Email

parts@bradfordwhite.com
techserv@bradfordwhite.com

www.bradfordwhite.com