



COMMERCIAL GAS REPLACEMENT PARTS LIST

High Efficiency Commercial Gas Series



Models Covered:
EF60T(125,150,199)(E*N)(*X)(A)2
EF100T(150,199,250,300) (E*N)(*X)(A)2
(Serial Number XC47471117 and After)

Includes Hydrojet® Total
Performance System


Effective: October, 2024
ECO 8859

NOTE: BOTH MODEL AND SERIAL
NUMBERS ARE REQUIRED FOR
ORDERING REPLACEMENT PARTS

Dimensions and specifications
subject to change without notice.




As required by the state of California Proposition 65.



Item	Description	Model	Model	Model
		EF60T125(E)*(N,X)(A)2	EF60T150(E)*(N,X)(A)2	EF60T199(E)*(N,X)(A)2
1	Combustion Surround Assembly	See Page 10	See Page 10	See Page 10
2	Combustion System Assembly	See Page 6	See Page 6	See Page 6
3	Collector Cover Second Pass	239-52975-00	239-52975-00	239-52975-00
4	Screw 10-16 x 3/4	239-44444-00	239-44444-00	239-44444-00
5	Elbow-Vent Terminal (2 Req'd)	---	---	---
	Elbow-Vent Terminal	415-40579-00	415-40579-00	415-40579-00
	Coupling-Vent Terminal	239-46740-00	239-46740-00	239-46740-00
6	Temperature Sensor	415-46553-02	415-46553-02	415-46553-02
7	Baffle 4" Flue (2 Req'd)	243-43304-00	243-43304-00	243-43304-00
8	Anode Rod (Powered) (2 Req'd)#	224-53839-00	224-53839-00	224-53839-00
9	Baffle 2" Flue (8 Req'd)	239-45659-00	239-45659-00	239-45659-00
10	Wire Harness-Service Panel	239-43358-02	239-43358-02	239-43358-02
11	Nipple Hot Water Outlet Platisert (Front Connect)	229-40913-07	229-40913-07	229-40913-07
12	Pipe Plug 1" NPT	239-02048-00	239-02048-00	239-02048-00
13	Nipple Platisert T&P	229-32762-02	229-32762-02	229-32762-02
14	T&P Relief Valve	415-30246-00	415-30246-00	415-30246-00
15	Exhaust Vent Pipe	239-45971-00	239-45971-00	239-45971-00
16	Condensate Elbow	415-43211-00	415-43211-00	415-43211-00
17	Silicone Tubing 3/16" I.D.	239-41718-00	239-41718-00	239-41718-00
18	Outer Door Service Panel	243-44668-00	243-44668-00	243-44668-00
19	Bracket Exhaust Support	239-44667-00	239-44667-00	239-44667-00
20	Escutcheon-Exhaust Pipe (EF Series)	239-43997-00	239-43997-00	239-43997-00
21	Exhaust Pressure Switch	415-46037-01	415-46037-01	415-46037-01
22	Keps Nut (2 Req'd)	239-81844-00	239-81844-00	239-81844-00
23	Hi-Limit Switch	415-43238-02	415-43238-02	415-43238-02
24	Screw 6-32 x 3/8 (2 Req'd)	239-81843-00	239-81843-00	239-81843-00
25	Cleanout Cover	205-18428-00	205-18428-00	205-18428-00
25	Cleanout Cover (ASME)	205-32941-00	205-32941-00	205-32941-00
26	Cleanout Gasket	205-18427-00	205-18427-00	205-18427-00
26	Cleanout Gasket (ASME)	205-32942-00	205-32942-00	205-32942-00
27	Screw 5/16 - 18 x 1/2	239-82166-00	239-82166-00	239-82166-00
27	Screw 5/16 - 18 x 1/2 (ASME) (6 Req'd)	239-32970-00	239-32970-00	239-32970-00
28	Clean Out Access Cover	243-20299-00	243-20299-00	243-20299-00
29	Dip Tube w/ Nipple Hydrojet (Front Connect)	415-44375-00	415-44375-00	415-44375-00
30	Drain Valve Brass (No Handle)	415-42351-02	415-42351-02	415-42351-02
31	Coaxial Vent Pipe with Terminal (Optional)	415-44069-01	415-44069-01	415-44069-01
32	Approved Mixing Valve (Optional)	239-51778-00	239-51778-00	239-51778-00
33	Reducer 3" x 2"	---	---	---
34	Hole Closure	239-31547-02	239-31547-02	239-31547-02
35	Sensor Well	233-46558-01	233-46558-01	233-46558-01
36	Clip Thermostat	233-45242-00	233-45242-00	233-45242-00
37	Screw 1/4-20 x 5/8 Hex Washer (2 Req'd)	239-42637-00	239-42637-00	239-42637-00
38	ICON Control Box and Wiring	243-54158-00	243-54158-00	243-54158-00
39	Kit-Cleanout (Not For Use With ASME Tanks)	415-54256-00	415-54256-00	415-54256-00

* Applies to all warranties




Item	Description	Model	Model	Model	Model
		EF100T150(E)*(N,X)(A)2	EF100T199(E)*(N,X)(A)2	EF100T250(E)*(N,X)(A)2	EF100T300(E)*(N,X)(A)2
1	Combustion Surround Assembly	See Page 12	See Page 12	See Page 12	See Page 12
2	Combustion System Assembly	See Page 8	See Page 8	See Page 8	See Page 8
3	Collector Cover Second Pass	239-52975-00	239-52975-00	239-52975-00	239-52975-00
4	Screw 10-16 x 3/4	239-44444-00	239-44444-00	239-44444-00	239-44444-00
5	Elbow-Vent Terminal (2 Req'd)	---	---	---	---
	Elbow-Vent Terminal	415-40579-00	415-40579-00	415-40579-00	415-40579-00
	Coupling-Vent Terminal	239-46740-00	239-46740-00	239-46740-00	239-46740-00
6	Temperature Sensor	415-46553-02	415-46553-02	415-46553-02	415-46553-02
7	Baffle 4" Flue (2 Req'd)	---	243-43304-00	243-43304-00	243-43304-00
8	Anode Rod (Powered) (2 Req'd)#	224-53839-00	224-53839-00	224-53839-00	224-53839-00
9	Baffle 2" Flue (8 Req'd)	239-45658-00	239-45658-00	239-45658-00	239-45658-00
10	Wire Harness-Service Panel	239-43358-01	239-43358-01	239-43358-01	239-43358-01
11	Nipple Hot Water Outlet Plastisert (Front Connect)	229-40913-07	229-40913-07	229-40913-07	229-40913-07
12	Pipe Plug 1" NPT	239-02048-00	239-02048-00	239-02048-00	239-02048-00
13	Nipple Plastisert T&P	229-32762-02	229-32762-02	229-80982-00	229-80982-00
14	T&P Relief Valve	415-30246-00	415-30246-00	415-33630-04	415-33630-04
15	Exhaust Vent Pipe	239-45971-00	239-45971-00	239-45971-00	239-45971-00
16	Condensate Elbow	415-43211-00	415-43211-00	415-43211-00	415-43211-00
17	Silicone Tubing 3/16" I.D.	239-41718-00	239-41718-00	239-41718-00	239-41718-00
18	Outer Door Service Panel	243-44668-00	243-44668-00	243-44668-00	243-44668-00
19	Bracket Exhaust Support	239-44667-00	239-44667-00	239-44667-00	239-44667-00
20	Escutcheon-Exhaust Pipe (EF Series)	239-43997-00	239-43997-00	239-43997-00	239-43997-00
21	Exhaust Pressure Switch	415-46037-01	415-46037-01	415-46037-01	415-46037-01
22	Keps Nut (2 Req'd)	239-81844-00	239-81844-00	239-81844-00	239-81844-00
23	Hi-Limit Switch	415-43238-02	415-43238-02	415-43238-02	415-43238-02
24	Screw 6-32 x 3/8 (2 Req'd)	239-81843-00	239-81843-00	239-81843-00	239-81843-00
25	Cleanout Cover	205-18428-00	205-18428-00	205-18428-00	205-18428-00
25	Cleanout Cover (ASME)	205-32941-00	205-32941-00	205-32941-00	205-32941-00
26	Cleanout Gasket	205-18427-00	205-18427-00	205-18427-00	205-18427-00
26	Cleanout Gasket (ASME)	205-32942-00	205-32942-00	205-32942-00	205-32942-00
27	Screw 5/16 - 18 x 1/2	239-82166-00	239-82166-00	239-82166-00	239-82166-00
27	Screw 5/16 - 18 x 1/2 (ASME) (6 Req'd)	239-32970-00	239-32970-00	239-32970-00	239-32970-00
28	Clean Out Access Cover	243-20299-00	243-20299-00	243-20299-00	243-20299-00
29	Dip Tube w/ Nipple Hydrojet (Front Connect)	415-44375-00	415-44375-00	415-44375-00	415-44375-00
30	Drain Valve Brass (No Handle)	415-42351-02	415-42351-02	415-42351-02	415-42351-02
31	Coaxial Vent Pipe with Terminal (Optional)	415-44069-01	415-44069-01	415-44069-01	415-44069-01
32	Approved Mixing Valve (Optional)	239-51778-00	239-51778-00	239-51778-00	239-51778-00
33	Reducer 3" x 2"	---	---	---	---
34	Hole Closure	239-31547-02	239-31547-02	239-31547-02	239-31547-02
35	Sensor Well	233-46558-01	233-46558-01	233-46558-01	233-46558-01
36	Clip Thermostat	233-45242-00	233-45242-00	233-45242-00	233-45242-00
37	Screw 1/4-20 x 5/8 Hex Washer (2 Req'd)	239-42637-00	239-42637-00	239-42637-00	239-42637-00
38	ICON Control Box and Wiring	243-54158-00	243-54158-00	243-54158-00	243-54158-00
39	Kit-Cleanout (Not For Use With ASME Tanks)	415-54256-00	415-54256-00	415-54256-00	415-54256-00

* Applies to all warranties

Item	Description	Model	Model	Model	Model
		EF100T150(E)*(N,X)(A)2	EF100T199(E)*(N,X)(A)2	EF100T250(E)*(N,X)(A)2	EF100T300(E)*(N,X)(A)2
1	Combustion Surround Assembly	See Page 12	See Page 12	See Page 12	See Page 12
2	Combustion System Assembly	See Page 8	See Page 8	See Page 8	See Page 8
3	Collector Cover Second Pass	239-52975-00	239-52975-00	239-52975-00	239-52975-00
4	Screw 10-16 x 3/4	239-44444-00	239-44444-00	239-44444-00	239-44444-00
5	Elbow-Vent Terminal (2 Req'd)	---	---	---	---
	Elbow-Vent Terminal	415-40579-00	415-40579-00	415-40579-00	415-40579-00
	Coupling-Vent Terminal	239-46740-00	239-46740-00	239-46740-00	239-46740-00
6	Temperature Sensor	415-46553-02	415-46553-02	415-46553-02	415-46553-02
7	Baffle 4" Flue (2 Req'd)	---	243-43304-00	243-43304-00	243-43304-00
8	Anode Rod (Powered) (2 Req'd)#	224-53839-00	224-53839-00	224-53839-00	224-53839-00
9	Baffle 2" Flue (8 Req'd)	239-45658-00	239-45658-00	239-45658-00	239-45658-00
10	Wire Harness-Service Panel	239-43358-01	239-43358-01	239-43358-01	239-43358-01
11	Nipple Hot Water Outlet Plastisert (Front Connect)	229-40913-07	229-40913-07	229-40913-07	229-40913-07
12	Pipe Plug 1" NPT	239-02048-00	239-02048-00	239-02048-00	239-02048-00
13	Nipple Plastisert T&P	229-32762-02	229-32762-02	229-80982-00	229-80982-00
14	T&P Relief Valve	415-30246-00	415-30246-00	415-33630-04	415-33630-04
15	Exhaust Vent Pipe	239-45971-00	239-45971-00	239-45971-00	239-45971-00
16	Condensate Elbow	415-43211-00	415-43211-00	415-43211-00	415-43211-00
17	Silicone Tubing 3/16" I.D.	239-41718-00	239-41718-00	239-41718-00	239-41718-00
18	Outer Door Service Panel	243-44668-00	243-44668-00	243-44668-00	243-44668-00
19	Bracket Exhaust Support	239-44667-00	239-44667-00	239-44667-00	239-44667-00
20	Escutcheon-Exhaust Pipe (EF Series)	239-43997-00	239-43997-00	239-43997-00	239-43997-00
21	Exhaust Pressure Switch	415-46037-01	415-46037-01	415-46037-01	415-46037-01
22	Keps Nut (2 Req'd)	239-81844-00	239-81844-00	239-81844-00	239-81844-00
23	Hi-Limit Switch	415-43238-02	415-43238-02	415-43238-02	415-43238-02
24	Screw 6-32 x 3/8 (2 Req'd)	239-81843-00	239-81843-00	239-81843-00	239-81843-00
25	Cleanout Cover	205-18428-00	205-18428-00	205-18428-00	205-18428-00
25A	Cleanout Cover (ASME)	205-32941-00	205-32941-00	205-32941-00	205-32941-00
26	Cleanout Gasket	205-18427-00	205-18427-00	205-18427-00	205-18427-00
26A	Cleanout Gasket (ASME)	205-32942-00	205-32942-00	205-32942-00	205-32942-00
27	Screw 5/16 - 18 x 1/2	239-82166-00	239-82166-00	239-82166-00	239-82166-00
27A	Screw 5/16 - 18 x 1/2 (ASME) (6 Req'd)	239-32970-00	239-32970-00	239-32970-00	239-32970-00
28	Clean Out Access Cover	243-20299-00	243-20299-00	243-20299-00	243-20299-00
29	Dip Tube w/ Nipple Hydrojet (Front Connect)	415-44375-00	415-44375-00	415-44375-00	415-44375-00
30	Drain Valve Brass (No Handle)	415-42351-02	415-42351-02	415-42351-02	415-42351-02
31	Coaxial Vent Pipe with Terminal (Optional)	415-44069-01	415-44069-01	415-44069-01	415-44069-01
32	Approved Mixing Valve (Optional)	239-51778-00	239-51778-00	239-51778-00	239-51778-00
33	Reducer 3" x 2"	---	---	---	---
34	Hole Closure	239-31547-02	239-31547-02	239-31547-02	239-31547-02
35	Sensor Well	233-46558-01	233-46558-01	233-46558-01	233-46558-01
36	Clip Thermostat	233-45242-00	233-45242-00	233-45242-00	233-45242-00
37	Screw 1/4-20 x 5/8 Hex Washer (2 Req'd)	239-42637-00	239-42637-00	239-42637-00	239-42637-00
38	ICON Control Box and Wiring	243-54158-00	243-54158-00	243-54158-00	243-54158-00
39	Kit-Cleanout (Not For Use With ASME Tanks)	415-54256-00	415-54256-00	415-54256-00	415-54256-00


* Applies to all warranties



Item	Description	Model	Model	Model
		EF60T125(E)*(N,X)(A)2	EF60T150(E)*(N,X)(A)2	EF60T199(E)*(N,X)(A)2
40	Combustion System Assembly (Nat)	265-54043-01	265-54043-02	265-54043-03
	Combustion System Assembly (L.P.)	265-54043-08	265-54043-09	265-54043-10
41	Blower and Gas Valve Assembly (Nat)	265-54044-01	265-54044-02	265-54044-03
	Blower and Gas Valve Assembly (L.P.)	265-54044-08	265-54044-09	265-54044-10
42	Burner Assembly EF	265-46024-00	265-46024-00	265-46024-00
43	Blower	415-51225-00	415-51225-00	415-54727-00
44	Hose Tubing 3/16" I.D.	239-41718-00	239-41718-00	239-41718-00
45	Burner Mounting Insert Gasket**	239-43197-00	239-43197-00	239-43197-00
46	Screw 10-32 x 3/4 SHCS (4 Req'd)	239-43273-00	239-43273-00	239-43273-00
47	Gasket Venturi to Blower	239-44654-00	239-44654-00	239-44654-00
48	Gas Valve Assembly (Nat)	265-54040-01	265-54040-02	265-54040-03
	Gas Valve Assembly (L.P.)	265-54041-01	265-54041-02	265-54041-03
49	Nipple 1/2 NPT X 3"	239-37047-00	239-37047-00	239-37047-00
50	Reducer 3/4 x 1/2 NPT	239-04474-00	239-04474-00	239-04474-00
51	Nipple 3/4 NPT x 7"	239-43373-00	239-43373-00	239-43373-00
52	2" x 3" Dia. Flex Reducer	239-40902-00	239-40902-00	239-40902-00
53	Inlet Tube (PVC)	239-43364-01	239-43364-01	239-43364-01
54	Gasket Blower Transition	239-43241-00	239-43241-00	239-43241-00
55	Screw 8-32 x 1/4 RHCR (4 Req'd)	239-43272-00	239-43272-00	239-43272-00
56	Flame Sensor Gasket	239-43371-00	239-43371-00	239-43371-00
57	Flame Sensor W/ Gasket	415-43232-00	415-43232-00	415-43232-00
58	Blower Transition Weldment	239-43201-00	239-43201-00	239-43201-00
59	Nut Hex Washer (4 Req'd)	239-43297-00	239-43297-00	239-43297-00
60	Spark Rod (w/ Gasket)	415-46481-00	415-46481-00	415-46481-00
61	Spark Rod Gasket	239-43370-00	239-43370-00	239-43370-00
62	Burner Mounting Gasket	239-43246-00	239-43246-00	239-43246-00
63	Burner Tube Kit (w/ Gasket)	415-53033-00	415-53033-00	415-53033-00
64	Burner Mounting Gasket	239-43246-00	239-43246-00	239-43246-00
65	Burner Mounting Insert	239-43167-00	239-43167-00	239-43167-00
66	Ground Wire Assembly 24" Green	239-51994-00	239-51994-00	239-51994-00
67	Gas Regulator Kit (optional)	243-45517-00	243-45517-00	243-45517-00
68	LP to Natural Gas Conversion Kit	265-54048-03	265-54048-02	265-54048-01

* Applies to all warranties


** Included with Item 42




Item	Description	Model	Model	Model	Model
		EF100T150(E)*(N,X)(A)2	EF100T199(E)*(N,X)(A)2	EF100T250(E)*(N,X)(A)2	EF100T300(E)*(N,X)(A)2
40	Combustion System Assembly (Nat)	265-54043-04	265-54043-05	265-54043-06	265-54043-07
	Combustion System Assembly (L.P.)	265-54043-11	265-54043-12	265-54043-13	265-54043-14
41	Blower and Gas Valve Assembly (Nat)	265-54044-04	265-54044-05	265-54044-06	265-54044-07
	Blower and Gas Valve Assembly (L.P.)	265-54044-11	265-54044-12	265-54044-13	265-54044-14
42	Burner Assembly EF	265-46024-00	265-46024-00	265-46024-00	265-46024-00
43	Blower	415-51225-00	415-54729-00	415-54729-00	415-54729-00
44	Hose Tubing 3/16" I.D.	239-41718-00	239-41718-00	239-41718-00	239-41718-00
45	Burner Mounting Insert Gasket**	239-43197-00	239-43197-00	239-43197-00	239-43197-00
46	Screw 10-32 x 3/4 SHCS (4 Req'd)	239-43273-00	239-43273-00	239-43273-00	239-43273-00
47	Gasket Venturi to Blower	239-44654-00	239-44654-00	239-44654-00	239-44654-00
48	Gas Valve Assembly (Nat)	265-54040-04	265-54040-05	265-54040-06	265-54040-07
	Gas Valve Assembly (L.P.)	265-54041-04	265-54041-05	265-54041-06	265-54041-07
49	Nipple 1/2 NPT X 3"	239-37047-00	239-37047-00	239-37047-00	239-37047-00
50	Reducer 3/4 x 1/2 NPT	239-04474-00	239-04474-00	239-04474-00	239-04474-00
51	Nipple 3/4 NPT x 7"	239-43373-00	239-43373-00	239-43373-00	239-43373-00
52	2" x 3" Dia. Flex Reducer	239-40902-00	239-40902-00	239-40902-00	239-40902-00
53	Inlet Tube (PVC)	239-43364-01	239-43364-01	239-43364-01	239-43364-01
54	Gasket Blower Transition	239-43241-00	239-43241-00	239-43241-00	239-43241-00
55	Screw 8-32 x 1/4 RHCR (4 Req'd)	239-43272-00	239-43272-00	239-43272-00	239-43272-00
56	Flame Sensor Gasket	239-43371-00	239-43371-00	239-43371-00	239-43371-00
57	Flame Sensor W/ Gasket	415-43232-00	415-43232-00	415-43232-00	415-43232-00
58	Blower Transition Weldment	239-43201-00	239-43201-00	239-43201-00	239-43201-00
59	Nut Hex Washer (4 Req'd)	239-43297-00	239-43297-00	239-43297-00	239-43297-00
60	Spark Rod (w/ Gasket)	415-46481-00	415-46481-00	415-46481-00	415-46481-00
61	Spark Rod Gasket	239-43370-00	239-43370-00	239-43370-00	239-43370-00
62	Burner Mounting Gasket	239-43246-00	239-43246-00	239-43246-00	239-43246-00
63	Burner Tube Kit (w/ Gasket)	415-53033-00	415-53033-00	415-53033-00	415-53033-00
64	Burner Mounting Gasket	239-43246-00	239-43246-00	239-43246-00	239-43246-00
65	Burner Mounting Insert	239-43167-00	239-43167-00	239-43167-00	239-43167-00
66	Ground Wire Assembly 24" Green	239-51994-00	239-51994-00	239-51994-00	239-51994-00
67	Gas Regulator Kit (optional)	243-45517-00	243-45517-00	243-45517-00	243-45517-00
68	LP to Natural Gas Conversion Kit	265-54048-07	265-54048-06	265-54048-05	265-54048-04

* Applies to all warranties


** Included with Item 42



Item	Description	Model	Model	Model
		EF60T125(E)*(N,X)(A)2	EF60T150(E)*(N,X)(A)2	EF60T199(E)*(N,X)(A)2
69	Keeper Latch & Catch	239-43239-00	239-43239-00	239-43239-00
70	Screw 8-32 x 1/2 RHCR (2 Req'd)	239-41715-00	239-41715-00	239-41715-00
71	Surround Head-EF Comm.	243-45823-02	243-45823-02	243-45823-02
72	Main Power Switch	239-43234-00	239-43234-00	239-43234-00
73	Control Display-ICON System	415-54047-00	415-54047-00	415-54047-00
74	Ring Combustion Surround	239-47305-02	239-47305-02	239-47305-02
75	Combustion Surround Base	239-51296-02	239-51296-02	239-51296-02
76	Display to Integrated Control Harness	239-48168-00	239-48168-00	239-48168-00
77	Strain Relief Bushing (Power Cord)	239-80372-00	239-80372-00	239-80372-00




Item	Description	Model	Model	Model	Model
		EF100T150(E)*(N,X)(A)2	EF100T199(E)*(N,X)(A)2	EF100T250(E)*(N,X)(A)2	EF100T300(E)*(N,X)(A)2
69	Keeper Latch & Catch	239-43239-00	239-43239-00	239-43239-00	239-43239-00
70	Screw 8-32 x 1/2 RHCR (2 Req'd)	239-41715-00	239-41715-00	239-41715-00	239-41715-00
71	Surround Head-EF Comm.	243-45823-02	243-45823-02	243-45823-02	243-45823-02
72	Main Power Switch	239-43234-00	239-43234-00	239-43234-00	239-43234-00
73	Control Display-ICON System	415-54047-00	415-54047-00	415-54047-00	415-54047-00
74	Ring Combustion Surround	239-47305-02	239-47305-02	239-47305-02	239-47305-02
75	Combustion Surround Base	239-51296-02	239-51296-02	239-51296-02	239-51296-02
76	Display to Integrated Control Harness	239-48168-00	239-48168-00	239-48168-00	239-48168-00
77	Strain Relief Bushing (Power Cord)	239-80372-00	239-80372-00	239-80372-00	239-80372-00



Item	Description	Model	Model	Model
		EF60T125(E)*(N,X)(A)2	EF60T150(E)*(N,X)(A)2	EF60T199(E)*(N,X)(A)2
78	Transformer 120V to 24V	233-50559-00	233-50559-00	233-50559-00
79	Control Panel	239-50514-00	239-50514-00	239-50514-00
80	Module-ICON System	415-54156-01	415-54156-01	415-54156-01
81	Ground Wire	239-38951-88	239-38951-88	239-38951-88
82	T-Stat Sensor Harness	239-48587-00	239-48587-00	239-48587-00
83	High Voltage Spark Cable	265-50887-00	265-50887-00	265-50887-00
84	Flame Sensor Wire	239-48237-00	239-48237-00	239-48237-00
85	Blower Modulation Harness	239-48170-00	239-48170-00	239-48170-00
86	Wire Harness Low Fire Start	239-53460-00	239-53460-00	239-53460-00
87	Power Cord/Switch Harness	239-48171-00	239-48171-00	239-48171-00
88	Power Anode Module	239-46229-00	239-46229-00	239-46229-00
89	Power Anode Harness	239-46070-00	239-46070-00	239-46070-00
90	Blower Power Harness	239-48617-00	239-48617-00	239-48617-00
91	Rectifier Harness	239-43571-00	239-43571-00	239-43571-00
92	Powered Anode Control Harness	239-46247-00	239-46247-00	239-46247-00
93	Screw-#4-40 X 3/8 Pan	239-50731-00	239-50731-00	239-50731-00
94	Nut 8-32 Keps	239-80029-00	239-80029-00	239-80029-00
95	Screw-#8-18 X 1/2	239-32761-00	239-32761-00	239-32761-00
96	Power Cord-96"	239-44466-00	239-44466-00	239-44466-00

* Applies to all warranties



Item	Description	Model	Model	Model	Model
		EF100T150(E)*(N,X)(A)2	EF100T199(E)*(N,X)(A)2	EF100T250(E)*(N,X)(A)2	EF100T300(E)*(N,X)(A)2
78	Transformer 120V to 24V	233-50559-00	233-50559-00	233-50559-00	233-50559-00
79	Control Panel	239-50514-00	239-50514-00	239-50514-00	239-50514-00
80	Module-ICON System	415-54156-01	415-54156-01	415-54156-01	415-54156-01
81	Ground Wire	239-38951-88	239-38951-88	239-38951-88	239-38951-88
82	T-Stat Sensor Harness	239-48587-00	239-48587-00	239-48587-00	239-48587-00
83	High Voltage Spark Cable	265-50887-00	265-50887-00	265-50887-00	265-50887-00
84	Flame Sensor Wire	239-48237-00	239-48237-00	239-48237-00	239-48237-00
85	Blower Modulation Harness	239-48170-00	239-48170-00	239-48170-00	239-48170-00
86	Wire Harness Low Fire Start	239-53460-00	239-53460-00	239-53460-00	239-53460-00
87	Power Cord/Switch Harness	239-48171-00	239-48171-00	239-48171-00	239-48171-00
88	Power Anode Module	239-46229-00	239-46229-00	239-46229-00	239-46229-00
89	Power Anode Harness	239-46070-00	239-46070-00	239-46070-00	239-46070-00
90	Blower Power Harness	239-48617-00	239-48617-00	239-48617-00	239-48617-00
91	Rectifier Harness	239-43571-00	239-43571-00	239-43571-00	239-43571-00
92	Powered Anode Control Harness	239-46247-00	239-46247-00	239-46247-00	239-46247-00
93	Screw-#4-40 X 3/8 Pan	239-50731-00	239-50731-00	239-50731-00	239-50731-00
94	Nut 8-32 Keps	239-80029-00	239-80029-00	239-80029-00	239-80029-00
95	Screw-#8-18 X 1/2	239-32761-00	239-32761-00	239-32761-00	239-32761-00
96	Power Cord-96"	239-44466-00	239-44466-00	239-44466-00	239-44466-00

* Applies to all warranties



United States

Sales	1-800-523-2931
Technical Support	1-800-334-3393
Email	<i>techsupport@bradfordwhite.com</i>
Warranty	1-800-531-2111
Email	<i>warranty@bradfordwhite.com</i>
Service Parts	1-800-538-2020
Email	<i>parts@bradfordwhite.com</i>

Canada

Sales	1-866-690-0961 1-905-203-0600
Fax	905-636-0666
Warranty	1-800-531-2111
Email	<i>warranty@bradfordwhite.com</i>
Technical Support	1-800-334-3393
Email	<i>techsupport@bradfordwhite.com</i>
Service Parts and Orders	<i>ca.orders@bradfordwhite.com</i>

For U.S. and Canada field service, contact your professional installer or local Bradford White sales representative.

International

General Contact	<i>international@bradfordwhite.com</i>
------------------------	---